



EDL Displays, Inc.

MICROPROCESSOR BOARD LIGHT AND DIP SWITCH DEFINITIONS

LIGHT DEFINITIONS

Light	Meaning (When On)
1	Normally Flashing
2	None
3	None
4	None
H	H DEFL ON
V	V DEFL ON
SYNC	SYNC ON
PWR	POWER ON

<input type="radio"/>	1
<input type="radio"/>	2
<input type="radio"/>	3
<input type="radio"/>	4
<input checked="" type="radio"/>	HDEF
<input checked="" type="radio"/>	VDEF
<input checked="" type="radio"/>	SYNC
<input checked="" type="radio"/>	PWR

DIP SWITCH SETTING DEFINITIONS

Switch	Label	Function
1	None	Monitor Address - 1
2	None	Monitor Address - 2
3	None	Monitor Address - 4
4	None	Monitor Address - 8
5	ERASEMEM	HI = Erase at Power On
6	ENAIN	HI = Disable Front Pnl Controls
7	ENAHREN	LO = Enable Horizontal Defl.
8	ENREM	HI = Apply external power to remote

